

### INTRODUCING

# THE EVERYDROP™ | WATER DISPENSER




The EveryDrop water dispenser magnetically attaches to top- or bottom-mount refrigerators. This dispenser removes lead and 28 contaminants\* from your family's drinking water. Plus, just one EveryDrop™ filter replaces 1,500 plastic water bottles\*\*, making this dispenser the obvious choice for customers looking to upgrade their refrigerator — without buying a new one.

## **EASY INSTALL**









Magnetically mounts to the **FRONT OR SIDE** of the refrigerator





# NO BOTTLES. NO PITCHERS. JUST FILTERED WATER.

Reduces WATER CONTAMINANTS





**REDUCES** lead

Easy **INSTALL** 





1 FILTER = 1500 water bottles"

MAGNETICALLY MOUNTS to your fridge





No pitcher means

MORE SHELF SPACE



The EveryDrop™
Dispenser uses
EveryDrop™
Refrigerator
Filter 1 (included).

#### **REPLACE EVERY:**



(200 gal/757 L)
Contaminant reduction
declines after **200 gallons.**