



KOWT100E

KitchenAid® 30" Slow Cook Warming Drawer

Dimensions: h: 10 1/4" w: 29 3/4" d: 26"

START THE CONVERSATION

How do you keep prepared dishes warm until they are ready to serve?

THIS MODEL OFFERS:

Custom-Control Technology

TOP FEATURES

CUSTOM-CONTROL TECHNOLOGY

Custom-Control Technology makes choosing settings quick and easy.

SLOW COOK FUNCTION

Slow Cook Function replaces a countertop slow cooker..

SENSOR TEMPERATURE CONTROL

Sensor Temperature Control monitors & maintains steady low heat.

DID YOU KNOW?

Use the control knob to quickly and easily select from defined temperature ranges for Food Warming, Bread Proofing and Slow Cooking. The SLOW COOK function in the warming drawer cooks food slowly at a low temperature over a long period of time, similar to a countertop slow cooker. There are 2 settings: Hi and Lo. Guidelines for cooking times are 4 to 5 hours for Hi and 8 to 10 hours for Lo. When slow cooking, use oven-safe serving pans or cookware.

DEMO

Demo on Your Sales Floor: Slide open this warming drawer to reveal the Custom Control Knob to your customers on the sales floor. Show them how simple it is to set for Food Warming, Bread Proofing and Slow Cooking. Keep a slow cooker on a countertop nearby to demonstrate the countertop or cabinet space your customers can save by installing this KitchenAid Warming Drawer in their home.

ALSO CONSIDER

RECOMMENDED PAIRINGS

Be sure to tune into your customers' shopping priorities to bundle products across categories.



KDTM604KBS



KCGS556ESS



KOSE500ESS



KRMF706EBS

1 OUT OF 5 KITCHEN APPLIANCE TRANSACTIONS INCLUDE MORE THAN ONE PRODUCT*

04/12/2021

®/TM © 2021 Whirlpool. All rights reserved. All other trademarks are owned by their respective companies.

KitchenAid®