



SELL IN
60 SECONDS




WFW3090GW

24" WASHER/ CONTRACT EXCLUSIVE MODEL 1.9 CU. FT. WASHER



Matching Dryer: WHD3090GW



WFP246W

Available color



W | White



Detergent Dosing Aid

Stop overdosing your detergent and help rid your clothes of residue. Detergent dosing aid helps you add the right amount of detergent to provide any load the right clean without the residue.

HOW: When you press the Start/Pause button to start the cycle, the drum will rotate to detect the load size. After a moment the display will show how much detergent (in mL) to add to the dispenser. Once the detergent has been added press and hold the Start/Pause button to continue the cycle.

HINT: Most standard measuring cups include mL.



Guided Mode

Once the washing machine is on, you can follow the guided mode displayed on the console for the right fabric care for your family's lifestyle.

HOW: Using just the main knob (that is also a button) you can navigate through all cycles and options available by turning the knob and pressing it.

HINT: Each cycle will still be displayed with their default options.



TumbleFresh™

Keep clothes fresh without having to immediately transfer them to the dryer. It activates after the wash cycle is finished and tumbles clean clothes periodically for up to 6 hours.

HOW: The TumbleFresh™ option will tumble the load at the end of the cycle every 3 minutes for 7 seconds, for up to 6 hours.

HINT: Once the TumbleFresh™ option is selected it will stay turned on for all future cycles until turned back off.

#1 SELLING APPLIANCE BRAND IN THE U.S.A.*

*Based on 12-month average of unit sales. Refrigeration, Cooking, Dishwashers and Laundry appliances. TraQline 2015. ©/™ ©2016 Whirlpool. All rights reserved. WL160142 | whirlpool.com



WHIRLPOOL CORPORATION
SALES ACADEMY