

WDT970SAHZ

TOP CONTROL DISHWASHER WITH THIRD LEVEL RACK

Shown in Fingerprint-Resistant Stainless Steel
Also available in White, Black and Fingerprint-Resistant Black Stainless



1

How often do you run your dishwasher?

2


Who helps with the dishes in your family?

**NO ONE HAS FEWER REPAIRS
20 YEARS IN A ROW***



Assembled in Findlay, Ohio

NO ONE HAS FEWER REPAIRS
20 YEARS
IN A ROW*



SELLING IN 60 SECONDS

1

35% MORE SPACE†

The third level rack is just the right spot for extra silverware, spatulas, large spoons or chef's knives.

2

TAP TOUCH CONTROLS

As easy to use as they are to clean, Tap Touch controls include LED indicators and cycle countdowns, so customers know when each cycle starts and stops.

3

THE RIGHT SETTINGS FOR EACH LOAD

The Sensor cycle automatically selects the ideal wash and dry settings for every load, using two sensors to measure soil level, load size and temperature.

DISHWASHER

*According a leading consumer magazine, Whirlpool® dishwashers. **Visit whirlpool.com for details and qualified models. †Compared to Whirlpool® dishwashers without a third level rack.



DID YOU KNOW?

Whirlpool brand stainless steel tub dishwashers have a 30-Day Money Back Clean & Quiet Guarantee.**

DEMO

Bring in spatulas, serving spoons and bottle lids and ask your customer where they would load them in the dishwasher. Guide them through the activity of placing the items in a dishwasher with a designated third level rack, compared to a model without one.



WANT TO LEARN MORE?

From LearnWhirlpool.com, access the Video Center and type “Third Level Rack” into the search field to watch in-depth videos about this feature.

**VISIT LEARNWHIRLPOOL.COM
FOR MORE INFORMATION**

**Visit whirlpool.com for details and qualified models.