



# KitchenAid®

KDTS324S

THIRD LEVEL JET RACK DISHWASHER WITH  
40+ TOTAL WASH JETS, 41 DBA

Dimensions: h: 33.625" w: 23.9375" d: 26.75"

Colors:  Black Ore  Black  Juniper

 PrintShield Stainless  White



## START THE CONVERSATION

How often do you have to scrub your dishes before you put them in the dishwasher to clean your dishes?

## TOP FEATURES



1

### 40+ TOTAL WASH JETS

provide complete cleaning coverage for dishes across all three racks, eliminating the need for pre-rinsing. With more than double the number of jets\* than the leading competitor's third rack model, it ensures targeted cleaning for dishes on every level.

2

### \*Compared to Bosch SHX9PCM5N THIRD LEVEL JET RACK

uses over a dozen dedicated wash jets to clean inside coffee mugs and cereal bowls. It also features a removable utensil tray.

3

### PRODRY™ SYSTEM

combines a heating element, water repellent tech, and natural ventilation to give you dry, table-ready dishes. To activate, select the ProDry™ Option or ProDry™ Max Option.



## DID YOU KNOW?

Consumers overwhelmingly prioritize wash performance as a top need for their dishwasher. The top 5 of 6 concerns all relate to cleaning performance.

\*Source: Dishwasher Habits, Practices, Needs & Gaps 2024

## HOW TO DEMONSTRATE



### 40+ TOTAL WASH JETS

Open the dishwasher and point out the 4 spray arms and explain that all those 40+ wash jets ensure dishes are cleaned with their total coverage targeted spray. Only the KitchenAid 6 & 7 series have more spray jets and wash arms

## ADDITIONAL PRODUCTS TO CONSIDER

Be sure to tune into your customers' shopping priorities to bundle products across categories



ALSO AVAILABLE / STEP UP

KDTS424S