KEY STEP-UP FEATURES



KOSC504P

- True Convection Oven
- Smart Appliance*
- Five-Level Rack Support
- Flush Installation
- Touchscreen Controls
- Self-Close Doors
- Self Cleaning



KOES527/30P

- + Air Fry (basket included)
- + Even-Heat™ True Convection
- + Integrated Meat Thermometer
- + SatinGlide™ Roll-Out **Extension Rack**
- + Even Heat Pre-heat
- + FIT System Guarantee**



KOSE900HSS

KOSE900HSS

UNDERSTAND THE MODEL NUMBERS

Use this handy tool to decode the model numbers for KitchenAid brand's built-in oven lineup.

KOSE900HSS

KOSE900HSS

K = KitchenAid®

PLATFORM

O = Wall Oven

CONFIGURATION

S = Single

C = True Convection

E = Even-Heat True Convection

KOSE900HSS **FEATURE LEVEL**

10-99 = The higher the number the more features available.

KODE900HSS WIDTH

4 = 24" 7 = 27" 0 = 30"

KOSE900HSS

YEAR OF LAUNCH

E = 2015H = 2018 P = 2023

KOSE900HSS COLOR

WH = White

SS = Stainless Steel

PS = Fingerprint Resistant Stainless

BS = Fingerprint Resistant Black Stainless



KOSE900H

- + Wi-Fi Connectivity*
- + Grill Attachment (included)
- + Steamer & Baking Stone Attachment (shipped separately)†
- + Recipe Guide Mode for **Powered Attachments**
- FIT System Guarantee**

+ Indicates Step-Up Feature

*Appliance must be set to remote enable. Wi-Fi & App required. Features subject to change. For details and privacy info, visit kitchenaid.com/connect. **On 27" and 30" single or double KitchenAid® Wall Ovens. Excludes new cabinet installations. Offer valid for qualified models of a compatible width and dates specified. Visit www.whirlpool.com/fit-guarantee.html for complete details. †Allow 10-15 days for delivery. Visit kitchenaid.com/redeem for full details.

®/TM © 2024 KitchenAid. All rights reserved.

SINGLE BUILT-IN OVEN







BUILT-IN OVENS MODELS	KOSC504P	KOES527P KOES530P	KOSE900H
AVAILABLE COLORS	PS	WH/SS/BS	SS/BS
CAPACITY (CU. FT.)	2.9	4.3 / 5.0	5.0
FLUSH INSTALL	•		
WIDTH	24"	27"/ 30"	30"
DETAILS			
CLEANING	Self-Cleaning	Self-Cleaning	Adjustable Self-Cleaning
COOKING SYSTEM	True Convection	True Convection	Convection
CONTROLS	Touchscreen	Digital	Full Color LCD
FIT SYSTEM LIMITED GUARANTEE*		•	•
INTERIOR COLOR	Grey	Blue	Black
TEMPERATURE PROBE	,	•	•
SATINGLIDE™ ROLL OUT EXTENSION		•	•
SELF-CLOSE/SOFT-CLOSE DOOR	•	•	
INTERIOR LIGHT	Halogen	Halogen	Halogen
SMART APPLIANCE**			
REMOTE START WITH THE WHIRLPOOL® APP	•	\bigcirc .	•
VOICE CONTROL WITH A COMPATIBLE VOICE-ENABLED DEVICE	•	<u> </u>	•
OVEN SETTINGS			
AIR FRY		•	
BAKE	•	•	•
BROIL	•	•	•
CANCEL/OFF	•	•	•
CONTROL LOCK	•	•	•
CONVECT MODES		•	•
COOK TIME INDICATOR	•	•	•
DELAY START	•	•	•
EASYCONVECT™ CONVERSION		•	
EVEN-HEAT™ PREHEAT		•	•
EVEN-HEAT™ TRUE CONVECTION		•	•
FAVORITES	•		•
FROZEN BAKE™ TECHNOLOGY	•		
FULL BAKE MEAL	•		
KEEP WARM/WARM HOLD	•	•	•
LANGUAGE CONVERSION	•	•	•
PROOFING	•	•	•
RAPID PREHEAT	•	•	•
SABBATH MODE	•	•	•
START TIME	•	•	•
STOP TIME	•		•
STEAM BAKE			•
TEMPERATURE CONVERSION	•	•	•
TEMPERATURE-SENSOR BAKING		•	•
ACCESSORIES			
AIR FRY BASKET		•	
BAKING STONE			•
GRILL ATTACHMENT			•
TRIM KIT	•		
STEAMER ATTACHMENT			•
DIMENSIONS			
- DIMENSIONS			
		00 0 (41) \(001) \(07 \) : ::::	

*On 27" and 30" single or double KitchenAid® Wall Ovens. Excludes new cabinet installations. Offer valid for qualified models of a compatible width and dates specified. Visit www.whirlpool.com/fit-guarantee.html for complete details. **Appliance must be set to remote enable. Wi-Fi & App required. Features subject to change. For details and privacy info, visit kitchenaid.com/connect.

27-15/16" X 23-7/16" X 24 3/4"

28-3/4" X 30" X 27-1/8"

28-3/4" X 27" X 27-1/8"

28-3/4" X 30" X 27-1/8"

HEIGHT X WIDTH X DEPTH (INCLUDING HANDLE)

KEY STEP-UP FEATURES



KODC504P

- True Convection Oven
- Smart Appliance*
- Five-Level Rack Support
- Flush Installation
- Touchscreen Controls
- Self-Close Doors
- Self Cleaning (upper only)



- + Even-Heat™ True Convection Oven (upper)
- + Temperature Probe (upper)
- + Even-Heat™ Preheat
- + FIT System Guarantee*
- + Easy Convect™ Conversion System



KOED527/30P

- + Air Fry (basket included) (upper)
- + Soft Close Doors
- + Integrated Meat Thermometer (upper)
- + SatinGlide™ Roll-Out Extension Rack (both)
- + Even-Heat™ True Convection Oven (both)
- Even-Heat[™] Preheat
- EasyConvect[™] Conversion System



KODE900H

- + Wi-Fi Connectivity*
- + Grill Attachment (included)
- + Steamer & Baking Stone Attachment (shipped separately)**
- + Recipe Guide Mode for Powered Attachments

UNDERSTAND THE MODEL NUMBERS

Use this handy tool to decode the model numbers for KitchenAid brand's built-in oven lineup.



K = KitchenAid®



O = Wall Oven



D = Double



C = True Convection

E = Even-Heat True Convection

KODE 90 0 HSS

10-99 = The higher the number the more features available.





E = 2015H = 2018 P = 2023

KODE900HSS

WH = White

SS = Stainless Steel

PS = Fingerprint Resistant Stainless

BS = Fingerprint Resistant Black Stainless

+ Indicates Step-Up Feature

*Appliance must be set to remote enable. Wi-Fi & App required. Features subject to change. For details and privacy info, visit kitchenaid.com/connect. **On 27" and 30" single or double KitchenAid® Wall Ovens. Excludes new cabinet installations. Offer valid for qualified models of a compatible width and dates specified. Visit www.whirlpool.com/fit-guarantee.html for complete details. †Allow 10-15 days for delivery. Visit kitchenaid.com/redeem for full details.

®/TM © 2024 KitchenAid. All rights reserved.

DOUBLE BUILT-IN OVEN









BUILT-IN OVENS MODELS	KODC504P	KODE300E	KOED527P KOED530P	KODE900H
AVAILABLE COLORS	PS	SS	SS/BS/PS	SS/BS
CAPACITY (CU. FT.)	5.2	10.0	8.6 / 10.0	10.0
FLUSH INSTALL	•			
WIDTH	24"	30"	27" / 30"	30"
DETAILS				
CLEANING	Self-Cleaning (upper)	Self-Cleaning	Self-Cleaning	Self-Cleaning
COOKING SYSTEM	True Convection	Convection	True Convection	Convection
CONTROLS	Touchscreen	Touchscreen	Digital	Full Color LCD
FIT SYSTEM LIMITED GUARANTEE*	Touchscreen	•	• Digital	• •
INTERIOR COLOR	Grey	Blue	Blue	Black
TEMPERATURE PROBE	Gley	•	•	•
			•	•
SATINGLIDE™ ROLL OUT EXTENSION		•		•
SELF-CLOSE/SOFT-CLOSE DOORS	•	11.1	•	11.1
INTERIOR LIGHT	Halogen	Halogen	Halogen	Halogen
SMART APPLIANCE**				
REMOTE START WITH THE WHIRLPOOL® APP	•			•
VOICE CONTROL WITH A COMPATIBLE VOICE-ENABLED DEVICE	•			•
OVEN SETTINGS				
AIR FRY			•	
BAKE	•		•	•
BROIL	•		•	•
CANCEL/OFF	•		•	•
CONTROL LOCK		•	•	•
CONVECT MODES	•		•	•
COOK TIME INDICATOR	•		•	•
DELAY START	•	•	•	•
EASYCONVECT™ CONVERSION		•	•	•
EVEN-HEAT™ PREHEAT		•	•	•
EVEN-HEAT™ TRUE CONVECTION		•	•	•
FAVORITES	•			•
FROZEN BAKE™ TECHNOLOGY	•			
FULL MEAL COOK	•			
KEEP WARM/WARM HOLD	•			•
LANGUAGE CONVERSION	•		•	•
PROOFING	•	•	•	•
RAPID PREHEAT			•	•
SABBATH MODE	•	•	•	•
START TIME	•	•	•	•
STOP TIME	•	•	•	•
STEAM BAKE	-			•
TEMPERATURE CONVERSION	•	•	•	•
TEMPERATURE-SENSOR BAKING	-	•	•	•
ACCESSORIES				
ARY FRY BASKET			•	
BAKING STONE			<u> </u>	•
GRILL ATTACHMENT				•
TRIM KIT	•			•
STEAMER ATTACHMENT	•			•
DIMENSIONS			F4 4 (41) V 20 2 (41) V 27 4 (01)	

HEIGHT X WIDTH X DEPTH (INCLUDING HANDLE)

50-1/4" X 23-7/16" X 22-1/2"

51-1/4" X 30" X 26-7/8"

51-1/4" X 29-3/4" X 27-1/8" 51-1/4" X 26-3/4" X 27-1/8"

51-1/4" X 30" X 27-1/8"

*On 27" and 30" single or double KitchenAid® Wall Ovens. Excludes new cabinet installations. Offer valid for qualified models of a compatible width and dates specified. Visit www.whirlpool.com/fit-guarantee.html for complete details. **Appliance must be set to remote enable. Wi-Fi & App required. Features subject to change. For details and privacy info, visit kitchenaid.com/connect.

KEY STEP-UP FEATURES



KOEC527/30P

- + Air Fry (basket included) (lower)
- + Soft Close Doors
- + SatinGlide™ Roll-Out Extension Rack
- + Even-Heat™ True Convection Oven (lower)
- + Microwave Convection Cooking (upper)
- EasyConvect[™] Conversion System
- + Crispwave Microwave Technology and Crisper Pan (upper oven)
- Integrated Meat Thermometer



KOCE900H

- + Wi-Fi Connectivity*
- + Grill Attachment (included)
- + Steamer & Baking Stone Attachment (shipped separately)**
- + Recipe Guide Mode for Powered Attachments

UNDERSTAND THE MODEL NUMBERS

Use this handy tool to decode the model numbers for KitchenAid brand's built-in oven lineup.



K = KitchenAid®



O = Wall Oven



C = Combination



E = Even-Heat True Convection



10-99 = The higher the number the more features available.



7 = 27"

0 = 30"



E = 2015

H = 2018

KOCE900HSS

WH = White

SS = Stainless Steel

PS = Fingerprint Resistant Stainless

BS = Fingerprint Resistant Black Stainless

+ Indicates Step-Up Feature

*Appliance must be set to remote enable. Wi-Fi & App required. Features subject to change. For details and privacy info, visit kitchenaid.com/connect. **On 27" and 30" single or double KitchenAid® Wall Ovens. Excludes new cabinet installations. Offer valid for qualified models of a compatible width and dates specified. Visit www.whirlpool.com/fit-guarantee.html for complete details. †Allow 10-15 days for delivery. Visit kitchenaid.com/redeem for full details.

®/TM © 2024 KitchenAid. All rights reserved.

COMBINATION BUILT-IN OVEN





AMAILABLE COLORS SS / BS (WH-527) 6.4 / 5.7 6.4 WDTH 27730' 30' DETAILS CLEANING CLEANING CLEANING CONING SYSTEM COOKING SYSTEM LIMITED GUARANTEE* INTERIOR COLOR Blue Blue Black ITEMPERATURE PROBE 1. SATINGLIDE* INTERIOR COLOR Blue Black INTERIOR LIGHT Halogen Halogen Malogen M	BUILT-IN OVENS MODELS	KOEC527P KOEC530P	КОСЕ900Н
### DETAILS CEANING	AVAILABLE COLORS	SS / BS (WH-527)	SS/BS
CLEANING Self-Cleaning Self-Cleaning COXING COXING COXING CONTROLS Digital Full color LCD FIT SYSTEM LIMITED GUARANTEE* INTERIOR COLOR Blue Black TEMPERATURE PROBE • • • • • • • • • • • • • • • • • • •	CAPACITY (CU. FT.)	6.4 / 5.7	6.4
CLEANING Self-Cleaning Self-Cleaning COOKING SYSTEM Convection Convection CONTROLS Digital Full Color LCD FIT SYSTEM LIMITED GUARANTEE* • • INTERIOR COLOR Blue Black TEMPERATURE PROBE • • SATINGLIDE™ ROLL OUT EXTENSION • • INTERIOR LIGHT Halogen Halogen SMART APPLIANCE** REMOTIE START WITH THE WHIRLPOOL® APP • VOICE CONTROL WITH A COMPATIBLE • CONTROL WITH A COMPATIBLE • CONTROL WITH A COMPATIBLE <td< td=""><td>WIDTH</td><td>27"/ 30"</td><td>30"</td></td<>	WIDTH	27"/ 30"	30"
CONVENTING SYSTEM CONVECTION Digital Full color LCD FIT SYSTEM LIMITED GUARANTEE* INTERIOR COLOR Blue Black TEMPERATURE PROBE INTERIOR COLOR Blue Black TEMPERATURE PROBE INTERIOR COLOR INTERIOR COLOR INTERIOR LIGHT Halogen Halogen INTERIOR LIGHT Halogen Halogen Mark APPULANCE* REMOTE START WITH THE WHIRL POOL® APP VOICE CONTROL WITH A COMPATIBLE VOICE ENABLED DEVICE VOICE CONTROL WITH A COMPATIBLE VOICE ENABLED DEVICE VOICE CONTROL WITH A COMPATIBLE VOICE MABELED DEVICE VOICE CONTROL WITH A COMPATIBLE VOICE MABELED DEVICE VOICE CONTROL WITH A COMPATIBLE VOICE MABELED DEVICE VOICE CONTROL WITH A COMPATIBLE VOICE CONTROL	DETAILS		
COOKING SYSTEM Convection Convection CONTROLS Digital Full color LCD IT SYSTEM LIMITED GUARANTEE* • • IT SYSTEM LIMITED GUARANTEE* • • INTERIOR COLOR Blue Black TEMPERATURE PROBE • • SATINGUIDE** ROLLOUT EXTENSION • • INTERIOR LIGHT Halogen Halogen SMART APPLIANCE*** • • REMOTE START WITH THE WHIRLPOOL® APP • • VOICE CONTROL WITH A COMPATIBLE • •	CLEANING	Self-Cleaning	Self-Cleaning
FIT SYSTEM LIMITED GUARANTEE*	COOKING SYSTEM		
INTERIOR COLOR	CONTROLS	Digital	Full Color LCD
TEMPERATURE PROBE	FIT SYSTEM LIMITED GUARANTEE*	•	•
SATINGLIDE™ ROLL OUT EXTENSION INTERIOR LIGHT Halogen Malogen SMART APPLIANCE** REMOTE START WITH THE WHIRLPOOL® APP VOICE CONTROL WITH A COMPATIBLE VOICE MARKE BROIL AIR FRY BAKE BROIL CANCEL/OFF CONTROL LOCK CONVECT MODES CONVECT MODES CONVECT MODES COOK TIME INDICATOR DELAY START EASYCONVECT™ CONVERSION EVEN-HEAT™ PREHEAT EVEN-HEAT™ TRUE CONVECTION FAVORITES EVEN-HEAT™ TRUE CONVECTION ARROLL AND ARR	INTERIOR COLOR	Blue	Black
INTERIOR LIGHT Halogen Halogen SMART APPLIANCE** REMOTE START WITH THE WHIRLPOOL® APP VOICE CONTROL WITH A COMPATIBLE VOICE CENTROL WITH A COMPATIBLE BROIL AIR FRY BAKE BROIL CANCEL/OFF CONTROLLOCK CONVECT MODES CONNECT MODES COOK TIME INDICATOR BELAY START COOK TIME INDICATOR BELAY START EVEN-HEAT™ PREHEAT EVEN-HEAT™ PREHEAT EVEN-HEAT™ TRUE CONVECTION FAVORITES KEEP WARMWARM HOLD LANGUAGE CONVERSION LANGUAGE CONVERSION PROOFING BAPID PREHEAT SABBATH MODE START TIME STOP TIME STOP TIME STOP TIME STOP TIME STOP TIME TEMPERATURE CONVERSION TEMPERATURE SENSOR BAKING MICROWAVE SETTINGS CRISP BAKE EASY CONVECT BAY CONVECT CRISP CRISP A CONVECT CRISP BAY CONVECT CRISP BAY CONVECT CRISP BAY CONVECT CRISP BAY CONVECT CRISP CRISP	TEMPERATURE PROBE	•	•
SMART APPLIANCE** REMOTE START WITH THE WHIRLPOOL® APP VOICE CONTROL WITH A COMPATIBLE VOICE FINABLED DEVICE OVEN SETTINGS AIR FRY BAKE I. I	SATINGLIDE™ ROLL OUT EXTENSION	•	•
REMOTE START WITH THE WHIRLPOOL® APP VOICE CONTROL WITH A COMPATIBLE VOICE-ENABLED DEVICE OVEN SETTINGS AIR FRY BAKE BROIL CANCEL/OFF CONTROL LOCK CONVECT MODES COOK TIME INDICATOR DELAY START EASYCONVECT "M CONVERSION EVEN-HEAT" PREHEAT EVEN-HEAT" PREHEAT EVEN-HEAT" PREHEAT EASYCONVECTSION FAVORITES KEEP WARMWARM HOLD LANGUAGE CONVERSION EAST DELAY START READ PROJEING FAYD PREHEAT STEAM BAKE STOP TIME STEAM BAKE CRISP CRICA CRISP CRICA	INTERIOR LIGHT	Halogen	Halogen
REMOTE START WITH THE WHIRLPOOL® APP VOICE CONTROL WITH A COMPATIBLE VOICE-ENABLED DEVICE OVEN SETTINGS AIR FRY BAKE BROIL CANCEL/OFF CONTROL LOCK CONVECT MODES COOK TIME INDICATOR DELAY START EASYCONVECT "M CONVERSION EVEN-HEAT" PREHEAT EVEN-HEAT" PREHEAT EVEN-HEAT" PREHEAT EASYCONVECTSION FAVORITES KEEP WARMWARM HOLD LANGUAGE CONVERSION EAST DELAY START READ PROJEING FAYD PREHEAT STEAM BAKE STOP TIME STEAM BAKE CRISP CRICA CRISP CRICA	SMART APPLIANCE**		
VOICE CONTROL WITH A COMPATIBLE VOICE ENABLED DEVICE VOEN SETTINGS AIR FRY BAKE BROIL CANCEL/OFF CONTROL LOCK CONTROL LOCK CONVECT MODES COOK TIME INDICATOR DELAY START BASYCONVECT TWO CONVERSION EVEN-HEAT** TRUE CONVERSION EVEN-HEAT** TRUE CONVECTION FAVORITES LANGUAGE CONVERSION PROOFING RAPID PREHEAT BABATH MODE START TIME STOP TIME STOP TIME STOP TIME STOP TIME STOP TIME STEAM BAKE TEMPERATURE SENSOR BAKING MICROWAVE SETTINGS CRISP DEFROST CRISP DEFROST CRISP DEFROST CRISP CRISP APP CONVECT OP CONVERSION TEMPERATURE SENSOR BAKING TEMPERATURE SENSOR BAKING OP CONVERSION TEMPERATURE SENSOR BAKING OP CONVECT OP CON			•
VOICE-RABLED DEVICE OVEN SETTINGS BAKE BROIL CANCEL/OFF CONTROLLOCK CONTROLLOCK CONYECT MODES COOK TIME INDICATOR DELAY START EASYCONVECT™ CONVERSION EVEN-HEAT™ PREHEAT EVEN-HEAT™ TRUE CONVECTION FAVORITES KEEP WARMWARM HOLD LANGUAGE CONVERSION PROOFING RAPID PREHEAT SABBATH MODE START TIME STOP TIME STOP TIME TEMPERATURE CONVERSION TEMPERATURE SENSOR BAKING MICROWAVE SETTINGS CRISP CRISP CRISP APPOCORN REHEAT SOFTEN/MELT SOFTEN/MELT SOFTEN/MELT SOFTEN/MELT SOFTEN/MELT SOFTEN/MELT SOFTEN/MELT ACCESSORIES ARY FRY BASKET BAKING STONE	VOICE CONTROL WITH A COMPATIBLE		
AIR FRY BAKE BROIL CANCEL/OFF CONTROL LOCK CONTYECT MODES COOK TIME INDICATOR DELAY START EASYCONVECT™ CONVERSION EVEN-HEAT™ FREHEAT EVEN-HEAT™ FREHEAT EVEN-HEAT™ TRUE CONVECTION FAVORITES KEEP WARMWARM HOLD LANGUAGE CONVERSION PROOFING RAPID PREHEAT SABBATH MODE START IIME STEAM BAKE TEMPERATURE CONVERSION BY CONVERSION TEMPERATURE SENSOR BAKING MICROWAVE SETTINGS CRISP CASYCONVECT EASY CONVECT POPCORN REHEAT ACCESSORIES ARY FRY BASKET BAKING STONE CONTROL OR	VOICE-ENABLED DEVICE		·
BAKE BROIL CANCEL/OFF CONTROL LOCK CONTROL LOCK CONVECT MODES COOK TIME INDICATOR DELAY START EASYCONVECT™ CONVERSION EVEN-HEAT™ PREHEAT EVEN-HEAT™ PREHEAT EVEN-HEAT™ TRUE CONVECTION FAVORITES KEEP WARMWARM HOLD LANGUAGE CONVERSION LANGUAGE CONVERSION FROOFING RAPID PREHEAT STEAM BAKE STOP TIME STEAM BAKE TEMPERATURE CONVERSION EVEN-BEATM TRUE CONVECTION FROOFING FROO	OVEN SETTINGS		
BROIL CANCEL/OFF CONTROL LOCK CONVECT MODES COOK TIME INDICATOR DELAY START EASYCONVECT™ CONVERSION EVEN_HEAT™ PREHEAT EVEN_HEAT™ TRUE CONVECTION FAVORITES KEEP WARM/WARM HOLD LANGUAGE CONVERSION PROOFING RAPIO PREHEAT SABBATH MODE START TIME STOP TIME STOP TIME STEAM BAKE TEMPERATURE CONVERSION PROOFING REPREATURE CONVERSION START TIME STOP TIME STEAM BAKE TEMPERATURE CONVERSION PROOFING REPREATURE CONVERSION REPREATURE CONVECT POPCORN REPREATURE CONVEC	AIR FRY	•	
CANCEL/OFF CONTROL LOCK CONVECT MODES COOK TIME INDICATOR DELAY START EASYCONVECT™ CONVERSION EVEN-HEAT™ PREHEAT EVEN-HEAT™ REPENDAT EVEN-HEAT™ TRUE CONVECTION FAVORITES KEEP WARM/WARM HOLD LANGUAGE CONVERSION PROOFING RAPID PREHEAT SABBATH MODE START TIME STOP TIME STOP TIME STEAM BAKE TEMPERATURE CONVERSION NETWORK BAKING MICROWAVE SETTINGS CRISP DEFROST EASY CONVECT POPCORN REHEAT STOP TIME STEAM BAKE TEMPERATURE SENSOR BAKING MICROWAVE SETTINGS CRISP ACCESSORIES ARY FRY BASKET BAKING STONE ■ CONVECT ON	BAKE	•	•
CONTROLLOCK CONVECT MODES COOK TIME INDICATOR COOK TIME ON THE CONVECTION COOK TIME C	BROIL	•	•
CONVECT MODES COOK TIME INDICATOR COOK TIME INDICATOR DELAY START EASYCONVECT™ CONVERSION EVEN-HEAT™ PREHEAT EVEN-HEAT™ TRUE CONVECTION FAVORITES KEEP WARM/WARM HOLD LANGUAGE CONVERSION PROOFING RAPID PREHEAT SABBATH MODE START TIME STEAM BAKE TEMPERATURE CONVERSION FINDINE STEAM BAKE TEMPERATURE SENSOR BAKING MICROWAVE SETTINGS CRISP DEFROST EASY CONVECT POPCORN EASY CONVECT STEAM ACCESSORIES ARY FRY BASKET BAKING STONE • • • • • • • • • • • • • • • • • •	CANCEL/OFF	•	•
COOK TIME INDICATOR DELAY START EASYCONVECT™ CONVERSION EVEN-HEAT™ PREHEAT EVEN-HEAT™ REHEAT EVEN-HEAT™ RIVE CONVECTION FAVORITES KEEP WARM/WARM HOLD LANGUAGE CONVERSION PROOFING RAPID PREHEAT SABBATH MODE START TIME STOP TIME STOP TIME STEAM BAKE TEMPERATURE CONVERSION PROOFING REPRATURE SENSOR BAKING MICROWAVE SETTINGS CRISP DEFROST EASY CONVECT POPCORN EASY CONVECT SOFTEN/MELT ACCCESSORIES ARY FRY BASKET BAKING STONE	CONTROL LOCK	•	•
BELAY START . . EASYCONVECT™ CONVERSION . . EVEN-HEAT™ PREHEAT . . EVEN-HEAT™ TRUE CONVECTION . . FAVORITES . . KEEP WARM/WARM HOLD . . LANGUAGE CONVERSION . . PROOFING . . RAPID PREHEAT . . SABBATH MODE . . START TIME . . STOP TIME . . STEAM BAKE . . TEMPERATURE CONVERSION . . TEMPERATURE-SENSOR BAKING . . MICROWAVE SETTINGS . . CRISP . . DEFROST . . EASY CONVECT . . POPCORN . . REHEAT . . SOFTEN/MELT . . STEAM . .	CONVECT MODES	•	•
EASYCONVECT™ CONVERSION EVEN-HEAT™ PREHEAT EVEN-HEAT™ TRUE CONVECTION FAVORITES KEEP WARM/WARM HOLD LANGUAGE CONVERSION PROOFING RAPID PREHEAT SABBATH MODE START TIME STOP TIME STOP TIME STEAM BAKE TEMPERATURE. SENSOR BAKING MICROWAVE SETTINGS CRISP DEFROST EASY CONVECT POPCORN REHEAT SOFTEN/MELT STEAM ACCESSORIES ARY FRY BASKET BAKING STONE • • • • • • • • • • • •	COOK TIME INDICATOR	•	•
EVEN-HEAT™ PREHEAT EVEN-HEAT™ TRUE CONVECTION FAVORITES KEEP WARM/WARM HOLD LANGUAGE CONVERSION PROOFING RAPID PREHEAT SABBATH MODE START TIME STOP TIME STOP TIME STEAM BAKE TEMPERATURE CONVERSION PEMPERATURE SENSOR BAKING CRISP DEFROST EASY CONVECT POPCORN REHEAT SOFTEN/MELT STEAM ACCESSORIES ARY FRY BASKET BAKING • • • • • • • • • • • • •	DELAY START	•	•
EVEN-HEAT™ TRUE CONVECTION • FAVORITES • KEEP WARM/WARM HOLD • • LANGUAGE CONVERSION • • PROOFING • • RAPID PREHEAT • • SABBATH MODE • • START TIME • • STOP TIME • • STEAM BAKE • • TEMPERATURE CONVERSION • • TEMPERATURE-SENSOR BAKING • • MICROWAVE SETTINGS • • CRISP • • DEFROST • • EASY CONVECT • • POPCORN • • SCFIEN/MELT • • STEAM • • ACCESSORIES • • AKING STONE • •	EASYCONVECT™ CONVERSION	•	
FAVORITES • KEEP WARM/WARM HOLD • LANGUAGE CONVERSION • PROOFING • RAPID PREHEAT • SABBATH MODE • START TIME • STOP TIME • STEAM BAKE • TEMPERATURE CONVERSION • TEMPERATURE-SENSOR BAKING • MICROWAVE SETTINGS • CRISP • DEFROST • EASY CONVECT • POPCORN • REHEAT • SOFTEN/MELT • STEAM • ACCESSORIES AKTERNAMENT • BAKING STONE •	EVEN-HEAT™ PREHEAT	•	
KEEP WARM/WARM HOLD • • LANGUAGE CONVERSION • • PROOFING • • RAPID PREHEAT • • SABBATH MODE • • START TIME • • STOP TIME • • STEAM BAKE • • TEMPERATURE CONVERSION • • TEMPERATURE-SENSOR BAKING • • MICROWAVE SETTINGS • • CRISP • • DEFROST • • EASY CONVECT • • POPCORN • • REHEAT • • SOFTEN/MELT • • STEAM • • ACCESSORIES • • BAKING STONE • •	EVEN-HEAT™ TRUE CONVECTION	•	•
LANGUAGE CONVERSION PROOFING RAPID PREHEAT SABBATH MODE START TIME STOP TIME STOP TIME STEAM BAKE TEMPERATURE CONVERSION TEMPERATURE SENSOR BAKING CRISP CRISP DEFROST EASY CONVECT POPCORN REHEAT SOFTEN/MELT STEAM ACCESSORIES ARY FRY BASKET BAKING SIONE	FAVORITES		•
PROOFING • • RAPID PREHEAT • • SABBATH MODE • • START TIME • • STOP TIME • • STEAM BAKE • • TEMPERATURE CONVERSION • • TEMPERATURE-SENSOR BAKING • • MICROWAVE SETTINGS • • CRISP • • DEFROST • • EASY CONVECT • • POPCORN • • REHEAT • • SOFTEN/MELT • • STEAM • • ACCESSORIES • • ARY FRY BASKET • • BAKING STONE • •	KEEP WARM/WARM HOLD	•	•
RAPID PREHEAT SABBATH MODE START TIME STOP TIME STOP TIME STEAM BAKE STEAM BAKE TEMPERATURE CONVERSION TEMPERATURE-SENSOR BAKING MICROWAVE SETTINGS CRISP DEFROST EASY CONVECT POPCORN REHEAT SOFTEN/MELT SOFTEN/MELT STEAM ACCESSORIES ARY FRY BASKET BAKING STONE • • • • • • • • • • • •	LANGUAGE CONVERSION	•	•
SABBATH MODE START TIME STOP TIME STOP TIME STEAM BAKE STEAM BAKE TEMPERATURE CONVERSION TEMPERATURE-SENSOR BAKING MICROWAVE SETTINGS CRISP DEFROST EASY CONVECT POPCORN REHEAT SOFTEN/MELT SOFTEN/MELT STEAM ACCESSORIES ARY FRY BASKET BAKING STONE • • • • • • • • • • • •	PROOFING	•	•
START TIME STOP TIME STEAM BAKE STEAM BAKE	RAPID PREHEAT	•	•
STOP TIME STEAM BAKE	SABBATH MODE	•	•
STEAM BAKE TEMPERATURE CONVERSION TEMPERATURE-SENSOR BAKING MICROWAVE SETTINGS CRISP DEFROST EASY CONVECT POPCORN REHEAT SOFTEN/MELT STEAM ACCESSORIES ARY FRY BASKET BAKING STONE • • • • • • • • • • • • •	START TIME	•	•
TEMPERATURE CONVERSION TEMPERATURE-SENSOR BAKING MICROWAVE SETTINGS CRISP DEFROST EASY CONVECT POPCORN REHEAT SOFTEN/MELT STEAM ACCESSORIES ARY FRY BASKET BAKING STONE • • • • • • • • • • • • • • • • • •	STOP TIME		•
TEMPERATURE-SENSOR BAKING MICROWAVE SETTINGS CRISP DEFROST EASY CONVECT POPCORN REHEAT SOFTEN/MELT STEAM ACCESSORIES ARY FRY BASKET BAKING STONE • • • • • • • • • • • • • • • • • •	STEAM BAKE		•
MICROWAVE SETTINGS CRISP •	TEMPERATURE CONVERSION	•	•
CRISP • • DEFROST • • EASY CONVECT • • POPCORN • • REHEAT • • SOFTEN/MELT • • STEAM • • ACCESSORIES - - ARY FRY BASKET • - BAKING STONE • -	TEMPERATURE-SENSOR BAKING	•	•
DEFROST EASY CONVECT POPCORN REHEAT SOFTEN/MELT STEAM ACCESSORIES ARY FRY BASKET BAKING STONE • • • • • • • • • • • • •	MICROWAVE SETTINGS		
EASY CONVECT • • POPCORN • • REHEAT • • SOFTEN/MELT • • STEAM • • ACCESSORIES - - ARY FRY BASKET • - BAKING STONE • -	CRISP	•	•
POPCORN • • REHEAT • • SOFTEN/MELT • • STEAM • • ACCESSORIES - - ARY FRY BASKET • - BAKING STONE • -	DEFROST	•	•
POPCORN • • REHEAT • • SOFTEN/MELT • • STEAM • • ACCESSORIES - - ARY FRY BASKET • - BAKING STONE • -		•	•
REHEAT SOFTEN/MELT STEAM ACCESSORIES ARY FRY BASKET BAKING STONE • • • • • • • • • • • • •		•	•
STEAM ACCESSORIES ARY FRY BASKET BAKING STONE • • • • • • • • • • • • • • • • • •		•	•
STEAM ACCESSORIES ARY FRY BASKET BAKING STONE • • • • • • • • • • • • • • • • • •	SOFTEN/MELT	•	•
ACCESSORIES ARY FRY BASKET BAKING STONE •		•	•
ARY FRY BASKET BAKING STONE •	ACCESSORIES		
BAKING STONE •		•	
		•	•
Chief in its affect			
STEAMER ATTACHMENT Optional •		Ontional	
DIMENSIONS DIMENSIONS			·

*On 27" and 30" single or double KitchenAid® Wall Ovens. Excludes new cabinet installations. Offer valid for qualified models of a compatible width and dates specified. Visit www.whirlpool.com/fit-guarantee.html for complete details. **Appliance must be set to remote enable. Wi-Fi & App required. Features subject to change. For details and privacy info, visit kitchenaid.com/connect.