



MFES6030R

30-INCH WIDE ELECTRIC RANGE WITH NO PREHEAT AIR FRY AND AIR BAKING - 5.3 CU. FT.

Dimensions: h: 47.875" w: 29.875" d: 28"

Colors: Black Fingerprint Resistant Stainless Steel

White



START THE CONVERSATION

Are you looking for a quick way to deliver crispy-on-the-outside food?

TOP FEATURES



1

NO PREHEAT AIR FRY


Enjoy crispy, golden results without the wait with No Preheat Air Fry



2

AIR BAKING

Make your favorite baked goods fast and more evenly with Air Baking



3

GRIDDLE ZONE

Griddle Zone turns your cooktop into a flat top *Sold Separately.

DID YOU KNOW?

Purchase the Air Fry Basket separately. Place the air fry basket on the middle rack. To avoid drips and crumbs from collecting on the bottom of your oven, place a baking tray on one of the racks below your air fryer basket.

HOW TO DEMONSTRATE



NO PREHEAT AIR FRY

Speak to our No Preheat Air Fry cycle by telling the customers how we have optimized the use of fan, ring element, bake and broil as well as the right heat at the right time delivering a crispy-on-the-outside, juicy-on-the-inside taste using little to no additional oil.*

*Compared to traditional deep frying.

ADDITIONAL PRODUCTS TO CONSIDER

Be sure to tune into your customers' shopping priorities to bundle products across categories



ALSO AVAILABLE / STEP UP
[MFES8030R](#)



SUITE MATCH COOKING RANGE / WALL OVEN
[MRSF4036P](#)



SUITE MATCH DISHWASHER
[MDB4949SK](#)