




MFGS4030R

**30-INCH WIDE GAS RANGE WITH STEAM
CLEAN - 5.0 CU. FT.**

Dimensions: h: 47.875" w: 29.875" d: 28"

Colors:  Black  Stainless Steel  White



START THE CONVERSATION

How often do you clean your current oven?

TOP FEATURES



1

STEAM CLEAN

Steam Clean cycle lifts stuck-on food in under an hour



2

EDGE-TO-EDGE DISHWASHER-SAFE CAST IRON GRATES

Edge-to-Edge Dishwasher-Safe Cast Iron Grates make cleanup hassle-free



3

POWER™ BURNER

Power™ Burner delivers intense heat for a serious sear

DID YOU KNOW?

"The Steam Clean feature is designed for light oven cavity bottom cleaning. Use the Steam Clean feature as soon as possible after spills occur. The longer a spill sits and dries in the oven, the more difficult it may be to remove"

HOW TO DEMONSTRATE



STEAM CLEAN

Point to the Steam Clean feature and how it is designed for light oven cavity cleaning. Speak to how it works by removing all racks and placing 10oz of water in the bottom of the oven cavity. The feature will take approximately 40 minutes and a tone will sound at the the end of the cycle.

ADDITIONAL PRODUCTS TO CONSIDER

Be sure to tune into your customers' shopping priorities to bundle products across categories



ALSO AVAILABLE / STEP UP
[MFGS6030R](#)



SUITE MATCH REFRIGERATOR
[MFI2570FE](#)



SUITE MATCH DISHWASHER
[MDB4949S](#)