



AMANA®

NED4655E

**6.5 CU. FT. ELECTRIC DRYER WITH
WRINKLE PREVENT OPTION**

Dimensions: h: 44" w: 29" d: 28.375"

Colors: White



START THE CONVERSATION

What items do you remove from the dryer before they are completely dry to help protect them from overdrying damage?

TOP FEATURES



1

AUTOMATIC DRYNESS CONTROL

Automatic Dryness Control uses temperature sensors to end the cycle at the right time to help prevent overdrying, so favorite items like comfy sweatpants get just the perfect dry.



2

WRINKLE PREVENT OPTION

When you can't fold right away, use the Wrinkle Prevent Option. It tumbles clothes intermittently without heat to help prevent creases and crinkles from settling in.



3

6.5 CU. FT. CAPACITY

6.5 cu. ft. Capacity can help take a load off your mind.

DID YOU KNOW?

A common concern for many customers is possible damage to fabrics as a result of overdrying. In fact, customers can often list a variety of items that they either don't place in the dryer or remove before the drying cycle is finished.

HOW TO DEMONSTRATE



AUTOMATIC DRYNESS CONTROL

Point to the Automatic Dry cycles on the dryer console and explain how those cycles use sensors to determine when fabrics are dry. Explain the difference between timed and automatic dry cycles.

ADDITIONAL PRODUCTS TO CONSIDER

Be sure to tune into your customers' shopping priorities to bundle products across categories