

Whirlpool

WDP730HAM

QUIET DISHWASHER WITH 3RD RACK AND POCKET HANDLE



Dimensions: h: 33.5" w: 23.875" d: 24.5" Colors: Singerprint Resistant Stainless Steel

START THE CONVERSATION

Where do you currently load large serving spoons, whisks, and spatulas?

TOP FEATURES



3RD RACK

2

Free up space for more dishes in the racks below with a 3rd Rack that makes it easy to load silverware, hard-to-fit utensils like tongs or even measuring cups and spoons.



ADJUSTABLE 2ND RACK

Manually raise or lower the upper rack two inches to better fit tall items with the Adjustable Upper Rack.



FAN DRYING TECHNOLOGY

Put dry dishes directly into your cabinet from the dishwasher. Fan Drying Technology pushes out moist air while helping pull in fresh, dry air.

DID YOU KNOW?

With 35% more rack space,* Whirlpool brand dishwashers with the third level rack allow customers to load more dishes and provide the right space for spatulas, large spoons or chef knives.*

*Compared to Whirlpool brand dishwashers without a third rack

HOW TO DEMONSTRATE



3RD RACK

Ask your customer where they normally place items like large spatulas, whisks, small measuring cups, or wooden spoons. Show them how these items take up less room in other areas by placing them in the third level rack.

ADDITIONAL PRODUCTS TO CONSIDER

Be sure to tune into your customers' shopping priorities to bundle products across categories



ALSO AVAILABLE / STEP UP WDT750SAK

© 2025 Whirlpool. All rights reserved.