



Whirlpool®

WED8620H

**7.4 CU. FT. FRONT LOAD ELECTRIC DRYER
WITH STEAM CYCLES**

Dimensions: h: 38.75" w: 27" d: 31"

Colors: Chrome Shadow White



START THE CONVERSATION

What items do you remove from the dryer before they're completely dry?

TOP FEATURES



1

ADVANCED MOISTURE SENSING

Advanced Moisture Sensing helps to prevent damage caused by overdrying by using three sensors to track moisture and temperature, adapting drying times to end the cycle at just the right time.



2

INTUITIVE CONTROLS

Let the dryer guide you to the right cycle combinations or customize up to 36 of your own to get the right type of fabric care for whatever you're drying.



3

STEAM REFRESH CYCLE

Release wrinkles and reduce odors with the Steam Refresh cycle. It uses water and heat to get clothes ready to wear without rewashing.

DID YOU KNOW? Sometimes the wax from dryer sheets can build up on moisture sensors. Use a damp cloth to refresh the sensor to accurately assess moisture within the drum.

HOW TO DEMONSTRATE



ADVANCED MOISTURE SENSING

Open the dryer door and point out the moisture sensing strips located on the back of the lint screen holder. Explain how the strips, along with the inlet and outlet thermistors, complete the Advanced Moisture Sensing system, which adapts drying times to provide the right amount of dry.

ADDITIONAL PRODUCTS TO CONSIDER

Be sure to tune into your customers' shopping priorities to bundle products across categories



ALSO AVAILABLE / STEP UP
[WED9620H](#)



LAUNDRY / PAIR WITH
[WFW8620H](#)