



WFES3030R

30-INCH ELECTRIC RANGE WITH NO PREHEAT MODE



Dimensions: h: 47.875" w: 29.875" d: 27.75"

Colors: Black Stainless Steel White

START THE CONVERSATION

Are you looking to ditch preheating and start frozen pizza or lasagna immediately?

TOP FEATURES



NO PREHEAT MODE

Take preheating off your plate with No Preheat Mode. Simply place your food in the oven and start baking. The oven will adjust the cook time for frozen pizzas and more.



2 BROIL

Redefine mealtime with Broil to make crispy-melty nachos, juicy-seared meat, toasty grilled cheese and more.



3 2 FLEXHEAT™ DUAL RADIANT ELEMENTS

Customize your element size for large or small cookware and boil 40% faster* with two FlexHeat™ Dual Radiant Elements, designed with a 6"" inner ring and 9" expandable outer ring.

Cook only 1 package of frozen food at a time when using No Preheat Mode

HOW TO DEMONSTRATE



NO PREHEAT MODE

Point to the No Preheat function on the range, tell your customers they will set the temperature as recommended on the food packaging. The cook time that appears in the display is the estimated required cook time as calculated by the oven control. It may be different than the time entered. A beep will alert you to check the food's doneness with at least 2 minutes remaining on the timer.

ADDITIONAL PRODUCTS TO CONSIDER

Be sure to tune into your customers' shopping priorities to bundle products across categories



ALSO AVAILABLE / STEP UP WFES3330R



SUITE MATCH REFRIGERATOR
WRS315SDH



SUITE MATCH DISHWASHER
WDT730HAM

© 2025 Whirlpool. All rights reserved.