




Whirlpool®

WFW862CH

**4.3 CU. FT. CLOSET-DEPTH FRONT LOAD
WASHER WITH LOAD & GO™ XL
DISPENSER**

Dimensions: h: 38.625" w: 27" d: 31.5625"

Colors:  Chrome Shadow



START THE CONVERSATION

How often do you guess how much detergent you need to use for a laundry load?

TOP FEATURES



1

LOAD & GO™ XL DISPENSER

Skip steps with the Load & Go™ XL dispenser. Simply add detergent once and skip refills for 40 loads(1).



2

12-HOUR FANFRESH® OPTION

Keep clothes fresh for up to 12 hours after the wash cycle has ended. A built-in fan activates after the wash cycle is over, tumbling clothes for up to 12 hours so you can finish laundry when you're ready.



3

INTUITIVE CONTROLS

Let the washer guide you to the right cycle combinations or customize up to 35 of your own to get the right type of fabric care for whatever you're washing.

DID YOU KNOW?

Too much detergent can leave residue on your clothes and even trap soils(2).
(2)Good Housekeeping 2019

HOW TO DEMONSTRATE



LOAD & GO™ XL DISPENSER

With the washer plugged in, point out how easy it is to set the detergent concentration by holding the "soil" and "temperature buttons. Take out the Load & Go™ XL dispenser and let customers know that the dispenser holds enough detergent for up to 40 loads(1). An indicator on the console lets them know when it's time to refill.

ADDITIONAL PRODUCTS TO CONSIDER

Be sure to tune into your customers' shopping priorities to bundle products across categories



ALSO AVAILABLE / STEP UP
[WFW8620H](#)



LAUNDRY / PAIR WITH
[WHD862CH](#)