



REFRIGERATION DEMO CODES



AMANA®

WHIRLPOOL®

MAYTAG®

KITCHENAID®

AMANA®

Whirlpool®

MAYTAG

KitchenAid®

AMANA® REFRIGERATION

Below are the instructions to put each Amana refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Amana lineup.

1

Hold the LIGHT and FAST COOL buttons down at the same time for THREE seconds.

2

Once control panel counts down from three seconds, model will be in demo mode.



MODELS
AFI2539ER



MODELS
ABB1921BRM
ABB1924BRM
ABB2224BRM

1

Turn temperature indicator down using the minus sign all of the way down.

2

Horizontal lines on temperature indicator will signal COOLING OFF.

DEMO CODES

AMANA® REFRIGERATION

Below are the instructions to put each Amana refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Amana lineup.

1

Press **TEMP SETTING** until you reach **MAX**. Hold door switch close to simulate door close. Press and hold **TEMP SETTING** for **THREE** seconds.

2

Unit enters **Showroom mode** and the UI perform **"Showroom Animation."**

MODELS

ASI2175GR
ASI2575GR



MODELS

ASI2275FR
ASI2575FR

1

Turn **REFRIGERATOR** control to the right so dial is pointed to **0 - OFF**. Turn **FREEZER** control to left so dial is pointed at **1**.

2

Cooling will turn off once **REFRIGERATOR** dial is set to **0 - OFF**.

AMANA® REFRIGERATION

Below are the instructions to put each Amana refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Amana lineup.



MODELS
ART308FFD
ART318FFD
ART348FFF

1

Hold TEMPERATURE SETTING button located on left of control panel for FOUR seconds.

2

Once all lights turn ON for ONE second, cooling will be turned off.



MODELS
ART106TFD

1


Turn temperature indicator dial to the left until pointed at OFF '0'.

2

Cooling will be off once the dial is set to OFF '0'.

AMANA® REFRIGERATION

Below are the instructions to put each Amana refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Amana lineup.



MODELS

ARTX2419S ARTX2021T
ARTX2019S ARTX2314T
ARTX2014T
ARTX2316T

1

Press and hold the power button on the temperature control panel for 4 seconds.

ADDITIONAL RESOURCES




LearnWhirlpool.com

Check out Learn Whirlpool for training materials, videos, games, and more!



Whirlpool Advantage App

This app will show you lineups of our models with each feature and spec. It updates too!



Your Whirlpool Rep

Keep up-to-date on products, store performance, and upcoming releases with your Whirlpool Sales Representative.

WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.

1

Hold the LIGHT and LOCK buttons down at the same time for THREE seconds.

2

Once control panel counts down from three seconds, model will be in demo mode.

MODELS

WRX735SDH	WRS970CID
WRS571CIH	WRS973CID
WRS588FIH	WRS975SID



1

Hold down the LIGHT and LOCK buttons at the same time for THREE seconds.

2

Once control panel counts down from three seconds, model will be in demo mode.

MODELS

WRX986SIH	WRV986FDE
WRF997SDD	WRV996FDE
WRV976FDE	



WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.

1

Hold the **LIGHT** and **FAST COOL** buttons down at the same time for **THREE** seconds.

2

Once control panel counts down from three seconds, model will be in demo mode.

MODELS

WRF555SDF
WRF555SDH



1

Hold the **FREEZER TEMP** and **FRIDGE TEMP** buttons down at the same time for **THREE** seconds.

2

Once control panel counts down from three seconds, model will be in demo mode.

MODELS

WRF560SEY



WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.



MODELS

WRF992FIF
WRF993FIF

1

Press the FRIDGE and FREEZER buttons located on the LED screen inside top console of refrigerator.

2

Once control panel counts down from three seconds, model will be in demo mode.

1

Hold the LIGHT and LOCK buttons down at the same time for THREE seconds.

2

Once control panel counts down from three seconds, model will be in demo mode.

MODELS

WRF757SDE
WRF767SDE



WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.

1

Hold the **DRAWER** and **F/C** buttons down at the same time for **THREE** seconds. Located within the door.

2

Once control panel counts down from three seconds, **'SHOWROOM'** will appear on control panel.

MODELS

WRF953CIH
WRF954CIH
WRF972SIH



1

Press and hold **COOLING ON/OFF** for **THREE** seconds.

2

LED will light up to indicate cooling is off. Press the **COOLING ON/OFF** button again to turn on cooling.

MODELS

WRF550CDH



WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.

1

Hold the **FREEZER TEMP** and **REFRIGERATOR TEMP** buttons down at the same time for **FIVE** seconds.

2

Once temperature indicator lights blink sequentially, model is in demo mode.
(Note: unplug, wait for two minutes, and plug model back in if it does not turn into demo mode upon first try.)

MODELS

WRS331SDH	WRS315SDH
WRS335SDH	WRS321SDH
WRS555SIH	WRS325SDH



1

Hold the **LOCK** and **FILTER** buttons down at the same time for **THREE** seconds.

2

Once control panel counts down from three seconds and **COOLING off** appears on display screen, cooling will be off.

MODELS

WRS586FIE



WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.



MODELS

WRT108FZD	WRT348FME
WRT138FZD	WRT518SZF
WRT318FZD	WRT549SZD
WRT318FMD	WSZ57L18D
WSR57R18D	

1

Hold the **SETTING** temperature button for **FOUR** seconds located on left of control panel.

2

Once all lights are illuminated for **ONE** second, cooling will be turned off.

1


Press **TEMP SETTING** until you reach **MAX**. Hold door switch close to simulate door close. Press and hold **TEMP SETTING** for **THREE** seconds.

2

Unit enters **Showroom** mode and the UI perform "Showroom Animation."


MODELS

WRS312SNH
WRS315SNH



WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.



MODELS

WRB119WFB	WRF532SMH
WRB322DMH	WRF535SMH
WRB322DMB	WRF535SWH
WRB329DMB	WRF540CWH

1

Turn either FREEZER or REFRIGERATOR buttons temperature buttons all the way down.

2

Horizontal lines on temperature indicator will signal COOLING OFF.



MODELS

WRF560SMH

1


Hold the FAST COOL and MOISTURE buttons down at the same time for THREE seconds.

2

Cooling will be turned off once buttons are held down for three seconds.

WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.



MODELS

WRT134TFD WRT314TFD
WRT104TFD WRT316SFD
WRT106TFD WRT111SFD

1

Turn temperature indicator dial to the left until pointed at OFF '0'.

2

Cooling will be off once the dial is set to OFF '0'.



MODELS

WRT311FZD WRT541SZD
WRT511SZD WRT541SZH
WRT519SZD

1

Turn dial to the right until the word OFF is in the center of the dial.

2

Cooling will be turned off once dial is set on the word OFF.

WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.

Look for the model number on the product label. Next to the model number there will be either "00" or "01".

If the number is "00", follow these instructions:

- 1 Press "Lock" to enter Lock status.
- 2 Press and hold "Refrigerator" + "Freezer" for FIVE seconds to enter service mode.
- 3 Press "Refrigerator" until the display shows "42".
- 4 Press "Freezer" to confirm Demo mode was selected, and the display shows "off".
- 5 Press "△" to open Demo mode, the display will show "on".
- 6 Press "Freezer" to confirm the Demo mode was opened. Exit Demo Mode: Exit automatic after Demo mode run ≥24h or replug the unit.

MODELS

WRFF3136S	WRMF3336S
WRFF3336S	WRMF3536S
WRFF3536S	WRMF3636S
WRFF3736S	WRMF3736S



If the number is "01", follow these instructions:

- 1 Click "Refrigerator" + "Freezer" + "Mode" three times in sequence within EIGHT seconds to enter service mode.
- 2 Press "△" until the display shows "42".
- 3 Press "Freezer" to confirm we have selected Demo mode, the display shows "off".
- 4 Press "△" to open Demo mode, the display will show "on".
- 5 Press "Freezer" to confirm the Demo mode was opened. Exit Demo Mode: Replug the unit.

WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.

MODELS

WRTX5419S	WRTX3021T
WRTX3119S	WRTX7421T
WRTX3019S	WRTX5118T
WRTX7419S	WRTX3114T
WRTX3319S	WRTX3314T
WRTX5519S	WRTX3316T
WRTX3219S	WRTX3014T
WRTX5421T	



1

Press and hold the power button on the temperature control panel for 4 seconds.

1

Hold the Refrigerator and Freezer temp buttons on the HMI for 5 seconds.

2

“Showroom” will illuminate on the HMI

MODELS

WRFC3036R	WRMC7036R
WRFC5036R	WRFC7436T
WRFC7036R	WRMC7436T
WRFC5236R	
WRMC5036R	



WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.

ADDITIONAL RESOURCES



LearnWhirlpool.com

Check out Learn Whirlpool for training materials, videos, games, and more!



Whirlpool Advantage App

This app will show you lineups of our models with each feature and spec. It updates too!



Your Whirlpool Rep

Keep up-to-date on products, store performance, and upcoming releases with your Whirlpool Sales Representative.

MAYTAG® REFRIGERATION

Below are the instructions to put each Maytag refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Maytag lineup.

1

Hold the **LIGHT** and **POWER COLD** buttons down at the same time for **THREE** seconds.

2

Once control panel counts down from three seconds, model will be in demo mode.

MODELS

MFI2570FE



1

Hold **REFRIGERATOR COOLING OFF** button for three seconds located to left on control panel.

2

Once control panel counts down from three seconds, model will be in demo mode.

MODELS

MFI2269FR



MAYTAG® REFRIGERATION

Below are the instructions to put each Maytag refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Maytag lineup.

1

Hold the **OPTIONS** and **WATER FILTER** buttons down at the same time for **THREE** seconds.

2

Once control panel counts down from three seconds, model will be in demo mode.



MODELS

MFT2776FE
MFX2676FR
MSC21C6MF
MSS26C6MF



MODELS

MFF2258FE
MFF2558FE
MBF1958FE
MBF2258FE

1

Turn temperature indicator down using the minus sign all of the way down.

2

Horizontal lines on temperature indicator will signal **COOLING OFF**.

MAYTAG® REFRIGERATION

Below are the instructions to put each Maytag refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Maytag lineup.



MODELS


MFC2062FE

1

Turn either **FREEZER** or **REFRIGERATOR** temperature buttons all the way down.

2

Horizontal lines on temperature indicator will signal **COOLING OFF**.



1

Hold the **SPEED COOL** and **MOISTURE CONTROL** buttons down at the same time for **THREE** seconds.

2

COOLING OFF will light up above **POWER COLD** when in demo mode.

MAYTAG® REFRIGERATION

Below are the instructions to put each Maytag refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Maytag lineup.



MODELS

MRT711SM

1

Hold the TEMP button for THREE seconds located on right of control panel.

2

All LEDs will turn on, only Power Cold LED will remain off.



MODELS

MRT118FF
MRT311FF

1

Put the setting in MAX position (coldest) Press and hold SW1 (tact switch) for FIVE seconds.

2

All LEDs turn on one by one from left to right and then right to left and keep cycling.

MAYTAG® REFRIGERATION

Below are the instructions to put each Maytag refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Maytag lineup.



MODELS

MRTX5119S MRTX7621T
MRTX5121T



Press and hold the temp setting button on the temperature control panel for 4 seconds.



Click "Refrigerator" + "Freezer" + "Mode" three times in sequence within 8 seconds to enter service mode.



Press "Δ" until the display shows "42".



Press "Freezer" to confirm we have selected Demo mode, the display shows "off".



Press "Δ" to open Demo mode, the display will show "on".



Press "Freezer" to confirm the Demo mode was opened.



Exit Demo Mode: Replug the unit.



MODELS

MRFF4336T MRMF5436T
MRFF5336T

MAYTAG® REFRIGERATION

Below are the instructions to put each Maytag refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Maytag lineup.

1

Hold the **FRIDGE TEMP** and **FREEZER TEMP** buttons down at the same time for **THREE** seconds.

2

Once control panel counts down from three seconds, model will be in demo mode.

MODELS
MFW2055FR



ADDITIONAL RESOURCES



LearnWhirlpool.com

Check out Learn Whirlpool for training materials, videos, games, and more!



Whirlpool Advantage App

This app will show you lineups of our models with each feature and spec. It updates too!



Your Whirlpool Rep

Keep up-to-date on products, store performance, and upcoming releases with your Whirlpool Sales Representative.

KITCHENAID® REFRIGERATION

Below are the instructions to put each KitchenAid refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the KitchenAid lineup.

1

Hold the LIGHT and LOCK buttons down at the same time for THREE seconds.

2

Once control panel counts down from three seconds, model will be in demo mode.

MODELS

KRFF507E
KRFF707E
KRFS505E



1

Hold down the LIGHT and LOCK buttons at the same time for THREE seconds.

2

Once control panel counts down from three seconds, model will be in demo mode.

MODELS

KRSC500E
KRSC503E



KITCHENAID® REFRIGERATION

Below are the instructions to put each KitchenAid refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the KitchenAid lineup.

1

Hold the LIGHT and LOCK buttons down at the same time for THREE seconds.

2

Once control panel counts down from three seconds, model will be in demo mode.

MODELS

KRMF606E
KRMF706E



1

Hold the DRAWER and F/C buttons down at the same time for THREE seconds. Located within the door.

2

Once control panel counts down from three seconds, 'SHOWROOM' will appear on control panel.

MODELS

KRFC604F
KRFC704F



KITCHENAID® REFRIGERATION

Below are the instructions to put each KitchenAid refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the KitchenAid lineup.

1

Press and Hold the [RC Temp] + [FC Temp] buttons for 5 seconds, the showroom indicator will blink twice to remain on/off.

MODELS

KRSC536R
KR5F536R



1

Press and Hold the Fridge and Freezer buttons for 5 seconds, the showroom indicator will blink twice to remain on/off.

MODELS

KBBL336S KBSD742S
KBFN536S KBSD748S
KBFN542S KBSN742S
KBSD736S KBSN748S



KITCHENAID® REFRIGERATION

Below are the instructions to put each KitchenAid refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the KitchenAid lineup.



MODELS


KRFC300E
KRFC302E
KRFF302E
KRFF305E

1

Turn either FREEZER or REFRIGERATOR temperature buttons all the way down.

2

Horizontal lines on temperature indicator will signal COOLING OFF.



MODELS

KRFF300E

1

Hold MOISTURE CONTROL and MAX COOL buttons for THREE seconds.

2

COOLING OFF will light up above MAX COOL when in demo mode.

KITCHENAID® REFRIGERATION

Below are the instructions to put each KitchenAid refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the KitchenAid lineup.



MODELS

KRBR102E	KRBX109E
KRBL102E	KRBR109E
KRBL109E	



Turn either **FREEZER** or **REFRIGERATOR** temperature buttons all the way down.



Horizontal lines on temperature indicator will signal **COOLING OFF**.



MODELS

KBBL206E	KBFN402E
KBBR206E	KBFN406E
KBBL306E	KBFN502E
KBBR306E	KBFN506E



Press the **FRIDGE** and **FREEZER** buttons located on the LED screen inside top console of refrigerator.



Once control panel counts down from **THREE** seconds, model will be in demo mode.

KITCHENAID® REFRIGERATION

Below are the instructions to put each KitchenAid refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the KitchenAid lineup.



MODELS

- | | |
|----------|----------|
| KBSN602E | KBSD608E |
| KBSD602E | KBSD612E |
| KBSD606E | KBSD618E |
| KBSN608E | |

1

Find and locate the **COOLING ON/OFF** button on the left of the control panel.

2

Press **COOLING ON/OFF** button to turn cooling off.

1

Hold the Refrigerator and Freezer temp buttons on the HMI for 5 seconds.

2

“Showroom” will illuminate on the HMI

MODELS

- | | |
|----------|----------|
| KRFC236S | KRFC936S |
| KRFC336S | KRFC536S |
| KRFC736S | KRFC636S |



KITCHENAID® REFRIGERATION

Below are the instructions to put each KitchenAid refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the KitchenAid lineup.

1

Click "Refrigerator" + "Freezer" + "Mode" three times in sequence within 8 seconds to enter service mode.

2

Press "△" until the display shows "42".

3

Press "Freezer" to confirm we have selected Demo mode, the display shows "off".

4

Press "△" to open Demo mode, the display will show "on".

5


Press "Freezer" to confirm the Demo mode was opened. Exit Demo Mode: Replug the unit.



MODELS

KRFF336S
KRFF436S
KRMF336S
KRMF436S

ADDITIONAL RESOURCES



LearnWhirlpool.com

Check out Learn Whirlpool for training materials, videos, games, and more!



Whirlpool Advantage App

This app will show you lineups of our models with each feature and spec. It updates too!



Your Whirlpool Rep

Keep up-to-date on products, store performance, and upcoming releases with your Whirlpool Sales Representative.

