

REFRIGERATION DEMO CODES









<u>AMANA®</u>

WHIRLPOOL®

MAYTAG®

<u>KITCHENAID</u>®







KitchenAid®

AMANA® REFRIGERATION

Below are the instructions to put each Amana refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Amana lineup.

1 Hold the LIGHT and FAST COOL buttons down at the same time for THREE seconds.

2 Once control panel counts down from three seconds, model will be in demo mode.



MODELS

AFI2539ER



MODELS

ABB1921BRM ABB1924BRM ABB2224BRM 1)

Turn temperature indicator down using the minus sign all of the way down.



Horizontal lines on temperature indicator will signal COOLING OFF.

AMANA® REFRIGERATION

Below are the instructions to put each Amana refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Amana lineup.

Press TEMP SETTING until you reach MAX. Hold door switch close to simulate door close. Press and hold TEMP SETTING for THREE seconds.

2 Unit enters Showroom mode and the UI perform "Showroom Animation."

MODELS

ASI2175GR ASI2575GR





MODELS

ASI2275FR ASI2575FR



Turn REFRIGERATOR control to the right so dial is pointed to 0 - OFF. Turn FREEZER control to left so dial is pointed at 1.



Cooling will turn off once REFRIGERATOR dial is set to 0 - OFF.

AMANA® REFRIGERATION

Below are the instructions to put each Amana refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Amana lineup.



MODELS

ART308FFD ART318FFD ART348FFF 1

Hold TEMPERATURE SETTING button located on left of control panel for FOUR seconds.

2

Once all lights turn ON for ONE second, cooling will be turned off.



MODELS

ART106TFD

1

Turn temperature indicator dial to the left until pointed at OFF '0'.



Cooling will be off once the dial is set to OFF '0'.

AMANA® REFRIGERATION

Below are the instructions to put each Amana refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Amana lineup.

ADDITIONAL RESOURCES



LearnWhirlpool.com

Check out Learn Whirlpool for training materials, videos, games, and more!



Whirlpool Advantage App

This app will show you lineups of our models with each feature and spec. It updates too!



Your Whirlpool Rep

Keep up-to-date on products, store performance, and upcoming releases with your Whirlpool Sales Representative. Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.

Hold the LIGHT and LOCK buttons down at the same time for THREE seconds.

Once control panel counts down from three seconds, model will be in demo mode.

MODELS

WRX735SDH WRS970CID WRS571CIH WRS973CID WRS588FIH WRS975SID



Hold down the LIGHT and LOCK buttons at the same time for THREE seconds.

Once control panel counts down from three seconds, model will be in demo mode.

MODELS

WRX986SIH WRV986FDE WRF997SDD WRV996FDE WRV976FDE



2



Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.

Hold the LIGHT and FAST COOL buttons down at the same time for THREE seconds.

Once control panel counts down from three 2 seconds, model will be in demo mode.



WRF555SDF WRF555SDH



Hold the FREEZER TEMP and FRIDGE TEMP buttons down at the same time for THREE seconds.

seconds, model will be in demo mode.



WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.



MODELS

WRF992FIF WRF993FIF 1

Press the FRIDGE and FREEZER buttons located on the LED screen inside top console of refrigerator.

2

Once control panel counts down from three seconds, model will be in demo mode.

Hold the LIGHT and LOCK buttons down at the same time for THREE seconds.

2

Once control panel counts down from three seconds, model will be in demo mode.



WRF757SDE WRF767SDE



WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.

Hold the DRAWER and F/C buttons down at the same time for THREE seconds. Located within the door.

Once control panel counts down from three seconds, 'SHOWROOM' will appear on control panel.

MODELS

WRF953CIH WRF954CIH WRF972SIH



Press and hold COOLING ON/OFF for THREE seconds.

2 LED will light up to indicate cooling is off. Press the COOLING ON/OFF button again to turn on cooling.

MODELS

WRF550CDH



WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.

Hold the FREEZER TEMP and REFRIGERATOR TEMP buttons down at the same time for FIVE seconds.

Once temperature indicator lights blink sequentially, model is in demo mode.

(Note: unplug, wait for two minutes, and plug model back in if it

does not turn into demo mode upon first try.)

MODELS

WRS331SDH WRS315SDH WRS335SDH WRS325SDH WRS325SDH



Hold the LOCK and FILTER buttons down at the same time for THREE seconds.

Once control panel counts down from three seconds and COOLING off appears on display screen, cooling will be off.

MODELS

WRS586FIE



WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.



MODELS

WRT108FZD WRT348FME WRT138FZD WRT518SZF WRT318FZD WRT549SZD WRT318FMD WSZ57L18D WSR57R18D

1

Hold the SETTING temperature button for FOUR seconds located on left of control panel.

2

Once all lights are illuminated for ONE second, cooling will be turned off.

Press TEMP SETTING until you reach MAX. Hold door switch close to simulate door close. Press and hold TEMP SETTING for THREE seconds.

2

Unit enters Showroom mode and the UI perform "Showroom Animation."



WRS312SNH WRS315SNH



WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.



MODELS

WRB119WFB WRF532SMH WRB322DMB WRF535SWH WRB329DMB WRF540CWH

1

Turn either FREEZER or REFRIGERATOR buttons temperature buttons all the way down.

2

Horizontal lines on temperature indicator will signal COOLING OFF.



MODELS

WRF560SMH

1

Hold the FAST COOL and MOISTURE buttons down at the same time for THREE seconds.

2

Cooling will be turned off once buttons are held down for three seconds.

WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.



MODELS

WRT134TFD WRT314TFD WRT104TFD WRT316SFD WRT106TFD WRT111SFD

1

Turn temperature indicator dial to the left until pointed at OFF '0'.

2

Cooling will be off once the dial is set to OFF '0'.



MODELS

WRT311FZD WRT541SZD WRT511SZD WRT541SZH WRT519SZD

1

Turn dial to the right until the word OFF is in the center of the dial.

2

Cooling will be turned off once dial is set on the word OFF.

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.

Look for the model number on the product label. Next to the model number there will be either "00" or "01".

If the number is "00", follow these instructions:

Press "Lock" to enter Lock status.

Press and hold "Refrigerator" + "Freezer" for FIVE seconds to enter service mode.

Press "Refrigerator" until the display shows "42".

Press "Freezer" to confirm Demo mode was selected, and the display shows "off".

Press "△" to open Demo mode, the display will show "on".

Press "Freezer" to confirm the Demo mode was opened. Exit Demo Mode: Exit automatic after Demo mode run ≥24h or replug the unit.



 $\nabla \blacksquare \blacksquare \triangle$

Whirlpool

Click "Refrigerator" + "Freezer" +
"Mode" three times in sequence within
EIGHT seconds to enter service mode.

Press " \triangle " until the display shows "42".

Press "Freezer" to confirm we have selected Demo mode, the display shows "off".

Press " \triangle " to open Demo mode, the display will show "on".

Press "Freezer" to confirm the Demo mode was opened. Exit Demo Mode: Replug the unit.

MODELS

WRFF3136S WRMF3336S WRFF3336S WRMF3536S WRFF3536S WRMF3636S WRFF3736S WRMF3736S

6

WHIRLPOOL® REFRIGERATION

Below are the instructions to put each Whirlpool refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Whirlpool lineup.

ADDITIONAL RESOURCES



LearnWhirlpool.com

Check out Learn Whirlpool for training materials, videos, games, and more!



Whirlpool Advantage App

This app will show you lineups of our models with each feature and spec. It updates too!



Your Whirlpool Rep

Keep up-to-date on products, store performance, and upcoming releases with your Whirlpool Sales Representative.

MAYTAG® REFRIGERATION

Below are the instructions to put each Maytag refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Maytag lineup.

Hold the LIGHT and POWER COLD buttons down at the same time for THREE seconds.

2 Once control panel counts down from three seconds, model will be in demo mode.



MFI2570FE



- 1 Hold REFRIGERATOR COOLING OFF button for three seconds located to left on control panel.
- 2 Once control panel counts down from three seconds, model will be in demo mode.



MFI2269FR



MAYTAG® REFRIGERATION

Below are the instructions to put each Maytag refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Maytag lineup.

Hold the OPTIONS and WATER FILTER buttons down at the same time for THREE seconds.

2 Once control panel counts down from three seconds, model will be in demo mode.



MFT2776FE MFX2676FR MSC21C6MF MSS26C6MF





MODELS

MFF2258FE MFF2558FE MBF1958FE MBF2258FE



Turn temperature indicator down using the minus sign all of the way down.



Horizontal lines on temperature indicator will signal COOLING OFF.

MAYTAG® REFRIGERATION

Below are the instructions to put each Maytag refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Maytag lineup.



MODELS

MFC2062FE



Turn either FREEZER or REFRIGERATOR temperature buttons all the way down.



Horizontal lines on temperature indicator will signal COOLING OFF.



MODELS

MFF2055FR



Hold the SPEED COOL and MOISTURE CONTROL buttons down at the same time for THREE seconds.



COOLING OFF will light up above POWER COLD when in demo mode.

MAYTAG® REFRIGERATION

Below are the instructions to put each Maytag refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Maytag lineup.



MODELS

MRT711SM

1

Hold the TEMP button for THREE seconds located on right of control panel.

2

All LEDs will turn on, only Power Cold LED will remain off.



MODELS

MRT118FF MRT311FF



Put the setting in MAX position (coldest) Press and hold SW1 (tact switch) for FIVE seconds.



All LEDs turn on one by one from left to right and then right to left and keep cycling.

MAYTAG® REFRIGERATION

Below are the instructions to put each Maytag refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the Maytag lineup.

1

Hold the FRIDGE TEMP and FREEZER TEMP buttons down at the same time for THREE seconds.

2

Once control panel counts down from three seconds, model will be in demo mode.



MFW2055FR



ADDITIONAL RESOURCES



LearnWhirlpool.com

Check out Learn Whirlpool for training materials, videos, games, and more!



Whirlpool Advantage App

This app will show you lineups of our models with each feature and spec. It updates too!



Your Whirlpool Rep

Keep up-to-date on products, store performance, and upcoming releases with your Whirlpool Sales Representative.

KITCHENAID® REFRIGERATION

Below are the instructions to put each KitchenAid refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the KitchenAid lineup.

Hold the LIGHT and LOCK buttons down at the same time for THREE seconds.

2 Once control panel counts down from three seconds, model will be in demo mode.



KRFF507E KRFF707E KRSF505E



Hold down the LIGHT and LOCK buttons at the same time for THREE seconds.

Once control panel counts down from three seconds, model will be in demo mode.



KRSC500E KRSC503E



DEMO COL

KITCHENAID® REFRIGERATION

Below are the instructions to put each KitchenAid refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the KitchenAid lineup.

Hold the LIGHT and LOCK buttons down at the same time for THREE seconds.

2 Once control panel counts down from three seconds, model will be in demo mode.



KRMF606E KRMF706E



Hold the DRAWER and F/C buttons down at the same time for THREE seconds. Located within the door.

Once control panel counts down from three seconds, 'SHOWROOM' will appear on control panel.



KRFC604F KRFC704F



KITCHENAID® REFRIGERATION

Below are the instructions to put each KitchenAid refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the KitchenAid lineup.



MODELS

KRFC300E KRFC302E KRFF302E KRFF305E 1

Turn either FREEZER or REFRIGERATOR temperature buttons all the way down.

2

Horizontal lines on temperature indicator will signal COOLING OFF.



MODELS

KRFF300E



Hold MOISTURE CONTROL and MAX COOL buttons for THREE seconds.



COOLING OFF will light up above MAX COOL when in demo mode.

KITCHENAID® REFRIGERATION

Below are the instructions to put each KitchenAid refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the KitchenAid lineup.



MODELS

KRBR102E KRBL102E KRBL109E KRBX109E KRBR109E 1

Turn either FREEZER or REFRIGERATOR temperature buttons all the way down.

2

Horizontal lines on temperature indicator will signal COOLING OFF.



MODELS

KBBL206E KBFN402E KBBR206E KBFN406E KBBL306E KBFN502E KBBR306E KBFN506E **1**)

Press the FRIDGE and FREEZER buttons located on the LED screen inside top console of refrigerator.

2

Once control panel counts down from THREE seconds, model will be in demo mode.

KITCHENAID® REFRIGERATION

Below are the instructions to put each KitchenAid refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the KitchenAid lineup.



MODELS

KBSN602E KBSD608E KBSD602E KBSD612E KBSD606E KBSD618E KBSN608E 1

Find and locate the COOLING ON/OFF button on the left of the control panel.



Press COOLING ON/OFF button to turn cooling off.

KITCHENAID® REFRIGERATION

Below are the instructions to put each KitchenAid refrigeration model into demonstration mode on your floor. Categorized by images of each control panel layout in the KitchenAid lineup.

- Click "Refrigerator" + "Freezer" + "Mode" three times in sequence within 8 seconds to enter service mode.
- **2** Press " \triangle " until the display shows "42".
- Press "Freezer" to confirm we have selected Demo mode, the display shows "off".
- Press " \triangle " to open Demo mode, the display will show "on".
- Press "Freezer" to confirm the Demo mode was opened. Exit Demo Mode: Replug the unit.



MODELS

KRFF336S KRFF436S KRMF336S KRMF436S

ADDITIONAL RESOURCES



LearnWhirlpool.com

Check out Learn Whirlpool for training materials, videos, games, and more!



Whirlpool Advantage App

This app will show you lineups of our models with each feature and spec. It updates too!



Your Whirlpool Rep

Keep up-to-date on products, store performance, and upcoming releases with your Whirlpool Sales Representative.

