



**Whirlpool®**

WTW5015L

**4.5 CU. FT. TOP LOAD AGITATOR WASHER  
WITH BUILT-IN FAUCET**

Dimensions: h: 41.5" w: 27.75" d: 27"

Colors:  White



## START THE CONVERSATION

How often do you prewash clothes before you put them in the washer?

## TOP FEATURES



1

### BUILT-IN WATER FAUCET

Easily prewash clothes and other items right in the washer with a conveniently located interior faucet that gives you easy access to an instant water stream to remove loose soils.



2

### DEEP WATER WASH OPTION

Get more water to help break down loose soils. This option fills your washer to the maximum water level so heavily soiled clothes get an optimal clean. Bulky Items cycle defaults to maximum water level.



3

### 360 WASH AGITATOR

Multiple wash motions gently move clothes up, down and side to side throughout the cycle, helping to loosen soils and provide a thorough clean in different water levels.

## DID YOU KNOW?

Easily prewash clothes and other items right in the washer with a conveniently located interior faucet that gives you easy access to an instant water stream to remove loose soils.

## HOW TO DEMONSTRATE



### BUILT-IN WATER FAUCET

Open the lid and show customers the water faucet and its on/off button. Explain that this feature allows for convenient pre-washing of clothes directly in the machine. Demonstrate how to activate the faucet by selecting the water faucet option on the cycle knob. Emphasize the benefit of spot treating and soaking clothes with cold water without needing to use a sink.

## ADDITIONAL PRODUCTS TO CONSIDER

Be sure to tune into your customers' shopping priorities to bundle products across categories



ALSO AVAILABLE / STEP UP  
[WTW8127L](#)



LAUNDRY / PAIR WITH  
[WED560LH](#)